



# Vacuum Pump Components & Accessories



- |                                |  |
|--------------------------------|--|
| 1) Primary shutoff             | 10) Suction filter (box type)              |
| 2) Secondary shutoff           | 11) Hydraulic transmission mounting flange |
| 3) Vacuum pump                 | 12) Flexible coupling                      |
| 4) Silencer / oil trap         | 13) Hydraulic motor mounting bracket       |
| 5) Heat exchanger-air / water  | 14) Hydraulic motor                        |
| 6) Expansion tank              | 15) Hydraulic pump                         |
| 7) 4-way valve                 | 16) Hydraulic control                      |
| 8) Non-return check valve      | 17) Heat exchanger - air / oil             |
| 9) Suction filter (round type) |  |

- 20) Man-ways
- 21) Automatic clamping unit
- 22) Split shaft PTO
- 23) Air suction filters
- 24) ADR's safety inside-valve
- 25) 4-way valves




# Vacuum Pump Components & Accessories



- 1) Heat exchanger
- 2) Gate valves
- 3) Ball valves
- 4) Safety valves
- 5) Rotating joints for hose reels
- 6) Stainless steel floating valves
- 7) Quick couplings



- 8) Suction pipe filter
- 9) High pressure hose guiding devices
- 10) High pressure spraying guns
- 11) Reaction nozzles
- 12) High pressure hoses



- 13) Spare parts supplies

